

## **Troubleshooting a Lincoln Town Car Air Suspension!**

*Strutmasters is your one stop shop for all Lincoln Town Car air suspension parts and suspension conversion kits.*

**Nov. 26, 2009** - [PRLog](#) -- Strutmasters is your one stop shop for all Lincoln Town Car air suspension parts and suspension conversion kits. Find Lincoln Towncar Monroe shock absorbers, struts, shocks, air springs, coil springs, air bags, air shocks, conversion kits, coil over air suspensions, air ride suspension conversions, helper springs, ride control suspension, suspension air compressors, air bag suspension components and Lincoln Town Car air ride suspension products. Have a suspension problem with your Lincoln Towncar rear suspension or front suspension? Strutmasters can help.

1. The Lincoln Town Car's air suspension uses a small, separate air compressor under the driver's side left fenderwell, with air lines running to the air bags. On the top of each air bag is a electrical valve. This is a relief valve that allows air to be exhausted when activated, and which senses the amount of air pressure within the air bag to keep both sides equal. These valves are operated via a leveling sensor that is attached to the body of the car and to the rear axle by a movable arm. When the rear of the car drops due to increased load, the arm is pushed up. When the arm is pushed up, it turns on the air compressor and fills the air bags to level the car. When the load is removed and the arm moves down, indicating that the back of the car has risen, the sensor opens the valve on the air bags and allows air to escape, lowering the car.

2. If the back of the car is low, indicating that the air suspension is not working, and the air suspension light is on, check the fuse first. If the fuse is all right, check the air suspension switch in the trunk and make sure it is on. This switch is used when the car is in for service. Always turn off the switch before lifting the car, because the sensor will think the car is rising and keep the air bag valves open, ruining the rear air suspension.

3. Turn the ignition key with the engine off. Listen for the compressor to come on while pushing down on the rear bumper. If it does not come on, test the switch terminals for power, using a circuit tester. If one terminal has power and the other does not, replace the switch. If there is power, turn the switch to the off position, raise the vehicle and place it on jack stands in the rear. Inspect the leveling switch on the axle, making sure it is not bent and is connected. Use an ohmmeter for this test. Pull the electrical connector off the switch. Loosen the arm of the switch from the axle. Test the switch with the ohmmeter by checking across both terminals while slowly moving the arm. There should be no continuity with the arm down. As the arm is raised, there should be continuity. If not, replace the switch. If there was continuity, connect the arm and the electrical connector.

###

Strutmasters is your one stop shop for all Lincoln Town Car air suspension parts and suspension conversion kits. Find Lincoln Towncar Monroe shock absorbers, struts, shocks, air springs, coil springs, air bags, air shocks, conversion kits, coil over air suspensions, air ride suspension conversions, helper springs, ride control suspension, suspension air compressors, air bag suspension components and Lincoln Town Car air ride suspension products. Have a suspension problem with your Lincoln Towncar rear suspension or front suspension? Strutmasters can help.

--- End ---

Source            Justin  
Country

United States  
Industry [Automotive](#)  
Tags [Lincoln Town Car](#), [Town Car](#), [Town Car Air Suspension](#), [Suspension Parts](#), [Automotive](#)  
Link <https://prlog.org/10429171>



Scan this QR Code with your SmartPhone to-

- \* Read this news online
- \* Contact author
- \* Bookmark or share online